Repair Process Board

E. TOPCOAT PREPARATION



Move vehicle into topcoat booth.



Degrease as per paint company recommendations.



Check and mix colour using 3MTM Paint Preparation System. Spray a test panel, assess and confirm the colour match and coverage using the 3MTM PPSTM Colour Check Light (16407).



Compare variant Colour Cards to the vehicle being repaired and choose the colour card that best represents the actual vehicle colour using the 3MTM PPSTM Colour Check Light (16407).



Check all masked areas. Tack off using 3MTM Tack cloth (07910).



Apply paint and bake as per paint company recommendations.

Version

3M MAR 10

