

# Repair Process Board

## C. MASKING OPTIONS



Use **3M™ Interior Protection Products (50588, 80308, 50595)** to protect the car interior throughout the repair process.



Use **3M™ Trim Masking Tape (06345/47/48/49)** on windscreens and components to provide complete protection from overspray.



Use **3M™ Trim Lifting Cord (09529)** under rubber mouldings to prevent a hard paint edge forming.



Use **3M™ Scotch Masking Tape 2328 in 36mm (50032)** for general masking and **Scotch™ High Performance Masking Tape 3434 in 19mm (07895)** for critical areas to optimise spend on masking tape.



Use **3M™ Premium Clear masking film (80139/50366)** to protect those area of the car not to be sprayed during the repair. One man application and clinging properties speed up masking times.



Use **3M™ Soft Edge Masking Foam Tape PLUS (50421)** for prevention of hard paint edges.



Use **3M™ Fine Line Masking Tape 471 in 3mm (06404)** and **6mm (06405)** for accurate masking and detailing.